

## **SET UP INSTRUCTIONS**





Screw support tubes together



Put base plate on bottom of support tube



Use M8 X 30mm screw and washer to attach base to support tube



Use M8 X 45mm screws and wing-nuts to attach back tray to support tube



Screw M4 X 16mm screws partially into back tray



Pull open dispenser cover



Hook dispenser on screws and tighten with screwdriver



Insert sanitizer tank into the holder and fill will sanitizer



Insert (qty 4) C batteries and turn on power switch



Close dispenser cover

